

# Modern Stair Light Kit Instructions

## Materials Needed:

- Power Drill with 7/16" drill bit
- Phillips Head Screwdriver
- Hammer



- 1 Plug the power cord into a 110 outlet.
- 2 Locate and drill a 7/16" hole in the riser, where the light will be mounted. Connect the micro-connector to the light fixture.
- 3 Connect the power supply to the first easy plug T-cable by plugging together the black connectors.
- 4 Continue to connect all the stair lights by plugging together each T-cable.
- 5 Use the wire staples to attach the wiring to the underside of the stairs.

500 Principio Parkway W.  
Unit 300  
North East, MD 21901

(410) 287-3232  
sales@ilightingLED.com  
www.ilightingLED.com

**\*\*\*To ensure a water tight seal, push connectors together.\*\*\***