



*Easy Plug Installation System.
Wiring Simply Plugs Together.*

POST LIGHT KIT INSTRUCTIONS

Materials Needed: Power Drill with 7/16" drill bit,
Phillips Head Screwdriver and a Hammer



No Wire Cutting

Installation Instructions:

1. Install the power supply with the instructions given.
2. Turn the system on by unplugging the black connector on the white wire and continue with installation. This unplugs the photo eye.
3. Locate and drill a 7/16" hole in the post sleeve where the light will be mounted.
4. Run the small lead down the inside of the sleeve, with the smaller connector out thru the 7/16" hole.
5. Slide the post sleeve over the post with the larger plug hanging out of the bottom or under the deck.
6. Plug the 60' lead from the post under deck to center on the "T" harness.
7. Connect the power supply to the first postlights harness by plugging the black connector together.
8. When finished installing all the lights reconnect the white wire to the photo eye from Step 2.
9. Continue to connect all the postlights together by plugging in together each harness.

For product or installation assistance please call (888) 305-4232.