

IR Dimmer Instructions



Lead from Power
Supply

Blue Light indicates
power is on.

Lead to First Light
Strip

- 1 Identify the location to mount the IR dimmer. Clean the area with the alcohol swab provided and let dry.
- 2 Be sure to install the dimmer before the first light strip or "Y" connector.
- 3 Connect the dimmer to the power supply and the blue light on the dimmer should come on.

*****If the blue light does not come on, install the twisted connector cable between the power supply and the touch dimmer.*****



- 4 Remove the double back tape and adhere the IR dimmer to the underside of the cabinet.
- 5 Swipe hand past sensor to turn the lights on and off.
- 6 Hold hand under sensor to dim or brighten the lights.
- 7 To retain same light brightness, hold hand under sensor until lights turn on.

*****Hold hand approximately 2" from sensor*****

500 Principio Parkway W.
Unit 300
North East, MD 21901

(410) 287-3232
sales@ilightingLED.com
www.ilightingLED.com